



Download  
Manual



Growatt New Energy

Shenzhen Growatt New Energy CO.,LTD  
4-13/F,Building A,Sino-German(Europe) Industrial Park,  
Hangcheng Ave, Bao'an District, Shenzhen, China

T +86 0755 2747 1942  
E service@ginverter.com  
W www.ginverter.com

GR-UM-180-A-03



## Installation Manual of SPH-UP series

# Index

## 1 Brief Introduction

- 1.1 Preface
- 1.2 Target Group
- 1.3 Glossary
- 1.4 Product Description
- 1.5 Safety Instructions

## 2 Safety

- 2.1 Purpose Use
- 2.2 Safety Measure
- 2.3 Symbols introduction on the SPH inverter

## 3 Product Description

- 3.1 SPH series inverter
- 3.2 Label Explanation
- 3.3 Size and weight
- 3.4 The advantage of the unit of SPH

## 4 Unpacking

## 5 Installation

- 5.1 Basic installation requirements
- 5.2 Installation requires tools and RJ 45 terminal sequence of the LAN line
- 5.3 Installation Instructions
- 5.4 SPH System Connection Mode

## 6 Commissioning

- 6.1 Commissioning of SPH
- 6.2 Operation modes
- 6.3 Display and button
- 6.4 Communication
- 6.5 Country setting

7 Start-up and shut down SPH system

- 7.1 Start-up the SPH system
- 7.2 Disconnect the SPH system
- 7.3 Export limitation and Power Sensor setting

8 Attention of the installation environment, maintenance and cleaning

9 Fault removal

- 9.1 Troubleshooting method when a fault occurs
- 9.2 System fault information list and troubleshooting suggestions

10 Manufacturer Warranty

11 Decommissioning

- 11.1 Dismantling the inverter
- 11.2 Package and transport SPH inverter
- 11.3 Storing SPH inverter
- 11.4 Disposing of the SPH inverter

12 Product specification

- 12.1 SPH series inverter machine product specification
- 12.2 DC input terminal parameter
- 12.3 Torque
- 12.4 Appendix

13 Certificate

14 Contact

# 1 Brief Introduction

## 1.1 Preface

This manual will provide the users who use the SPH Series of GROWATT NEW ENERGY TECHNOLOGY CO.LTD.SHENZHEN (Short for GROWATT New Energy as below) with the detailed product information and the installation instructions. Please read this manual carefully and put this manual on some place where is convenient to installation, operation, obtain. Any modifications of GROWATT new energy, we will not notify the user.

## 1.2 Target Group

SPH inverter must be installed by professional electrical personnel who have obtained the certification of the relevant departments.

We have two kinds of SPH inverter for different battery types, one is for lithium battery and the other is for lead-acid battery. We recommend customer should decide which kind of inverter if required prior to purchasing. GROWATT can only provide lithium battery that is compatible with inverter, no lead-acid battery will be provided by Growatt as customer can easily buy these from the market. It is dangerous if customer choose inverter compatible with lithium battery (which must be provide by GROWATT) but uses it for lead-acid battery or uses lead-acid battery for lithium battery inverter.

Installer can install SPH Series inverters rapidly, build communication system or troubleshoot by reading this manual carefully. If you have any questions in the process of installation, you can login in [www.growatt.com](http://www.growatt.com) and leave some message. Or you can call our 24-hour service hotline +86 (0)755 2747 1942

## 1.3 Glossary

### AC

Abbreviation for "Alternating Current"

### DC

Abbreviation for "Direct Current"

### Energy

Energy is measured in Wh (watt hours), kWh (kilowatt hours) or MWh (megawatt hours). The energy is the power calculated over time. For example, your inverter operates at a constant power of 4600 W for half an hour and then at a constant power of 2300 W for another half an hour, it has fed 3450Wh of energy into the power distribution grid within that hour.

### Power

Power is measured in W (watts), kW (kilowatts) or MW (megawatts). Power is an instantaneous value. It displays the power your inverter is currently feeding into the power distribution grid.

### Power rate

Power rate is the ratio of current power feeding into the power distribution grid and the maximum power of the inverter that can feed into the power distribution grid.

### Power Factor

Power factor is the ratio of true power or watts to apparent power or volt amps. They are identical only when current and voltage are in phase than the power factor is 1.0. The power in an ac circuit is very seldom equal to the direct product of the volts and amperes. In order to find the power of a single phase ac circuit the product of volts and amperes must be multiplied by the power factor.

### PV

Abbreviation for photovoltaic

### BAT

BAT is an acronym for lithium or lead acid battery

### Charging

An SPH hybrid inverter charger uses PV energy or grid energy to charge a must be multiplied by the power factor.

### Discharging

It means that the SPH hybrid inverter supplies the battery energy to the load

### wireless communication

The external wireless communication technology is a radio technology that allows the inverter and other communication products to communicate with each other. The external wireless communication does not require line of sight between the devices and it is selective purchasing.

## 1.4 Product Description

SPH Series is used to store energy generated by the photovoltaic cell panels or energy from grid if it is allowed in the battery, also energy can be sent to power grid through SPH for self consumption or when Grid power is lost, SPH can be used as backup power.

SPH series has six kinds of type:

- SPH 3000 TL BL-UP
- SPH 3600 TL BL-UP
- SPH 4000 TL BL-UP
- SPH 4600 TL BL-UP
- SPH 5000 TL BL-UP
- SPH 6000 TL BL-UP

Note: we describe this series as "SPH" as below.

Note: In different country, we provide different power. Such as in Germany, we can provide SPH 3000~SPH 4600TL BL-UP, but we don't provide SPH 5000TL BL-UP and SPH 6000TL BL-UP.

Overview:




Chart 1.1

| Position | Description   |
|----------|---|
| A        | USB interface   |
| B        | LED of status display                                     |
| C        | LCD screen  |
| D        | Function button   |
| E        | Dry contact   |
| F        | Battery terminal  |
| G        | VPP communication   |
| H        | RS485-2 communication                                     |
| I        | RS485-1 communication                                     |
| J        | NTC: Lead-acid temperature sensor terminal                |
| K        | CAN communication interface of Lithium battery            |
| L        | RJ45 interface of DRMs(used only in Australia)            |
| M        | RS485 communication interface of Merter/CT input terminal |
| N        | AC Grid (on grid connection)                              |
| O        | RSD(do not open except by Professional staff)             |
| P        | EPS output(off grid connection)                           |
| Q        | Ground point  |
| R        | PV input  |
| S        | PV switch   |

### 1.5 Safety Instructions

1. Please be clear which kind of battery system you want, lithium battery system or lead-acid battery system, if you choose the wrong system, SPH can't work normally.
2. Please read this manual carefully before the installation, the product warranty may be voided if the inverter is not installed according to the instructions of this manual for installation and cause equipment damage.
3. All the operation and connection please professional electrical or mechanical engineer.
4. During installation, please don't touch the other parts within the box.
5. All the electrical installation must comply with the local electrical safety standards.
6. If equipments needs to maintain, please contact with local specify system installation and maintenance personnel.
7. Connecting the equipment to the grid requires permission from the local power company
8. When install PV modules in the daytime, please turn off the PV switch, Otherwise it will be dangerous as high terminal voltage of modules in the sunshine.

# 2 Safety

## 2.1 Purpose Use

The system chart of SPH:




Chart 2.1

As shown above, a complete grid-connected system of SPH consists of PV modules, SPH inverter, battery, utility grid and other components.

### Attention:

As the system refer to battery use, we must make sure ventilation of the service environment and temperature control in order to prevent the danger of battery explosion, battery recommended installation environment must be strictly in accordance with the specification, if the specification is IP20 environment, the pollution degree of the unit is PD2, meanwhile the temperature should be control in the 0-40°C of indoor ventilation and the humidity should be 5%-85%. If the chosen PV modules needs to positive or negative ground connection, please contact with Growatt for technical support before installation.

## 2.2 Safety Measure



DANGER

**Risk of high voltage !**

- ◀ Relevant operation for professional personnel
- ◀ Please notice children, disabled, laypeople do not close
- ◀ Supervise and make sure children don't play near the installation position of inverter machine



DANGER

**Risk of burns on the parts shell of SPH inverter !**

During the work, Cover, shell around, radiator is likely to be hot



CAUTION

**SPH inverter exists radiation maybe affect health !**










Don't stay a long time within 20cm range from SPH inverter



**SPH inverter ground connection**



Please ensure SPH inverter ground connection is reliable for make sure people's safety

## 2.3 Symbols introduction on the SPH inverter


| Symbol  | Description   |
|---|---|
|    | Caution: Risk of electrical shock!  |
|    | Caution : hot surface   |
|    | Caution: risk of danger   |
|     | Danger to life due to high voltage in SPH<br>There is residual voltage in SPH, SPH requires 5 minutes to discharge.<br>Please wait 5 minutes before you open the upper lid or the DC lid. |
|    | Protective conductor terminal   |
|   | Direct Current(DC)  |
|  | Alternating Current(AC)   |
|  | The machine complies with the requirements of the applicable CE guidelines  |
|  | Refer to the operating instructions.  |

## 3.1 SPH series inverter

Marks of SPH

| Mark  | Description          | Explanation                                |                     |
|---|----------------------|--|---------------------|
|  | Push-button          | Operation of display screen and set system |                     |
|  | Status symbol of SPH | Green light on                             | SPH run normally    |
|   |                      | Red light on                               | Fault state         |
|   |                      | Green light blinking                       | 1.Alarm state       |
|   |                      | Red light blinking                         | 2.Software updating |

### 3.2 Label Explanation

| <b>GROWATT</b><br>Hybrid Inverter   |                       |
|---|-----------------------|
| Model name  | SPH 6000TL BL-UP      |
| <b>PV input data</b>  |                       |
| Max. PV voltage   | 550 d.c.V             |
| PV voltage range  | 120-550 d.c.V         |
| PV Isc  | 16.9 d.c.A*2          |
| Max. input current  | 13.5 d.c.A*2          |
| <b>AC output/input data</b>   |                       |
| Rated input/output power  | 6000/6000 W           |
| Rated output apparent power   | 6000 VA               |
| Nominal voltage   | 230 a.c.V             |
| Rated input/output current  | 27/27 a.c.A           |
| Nominal Frequency   | 50 Hz                 |
| Power factor range  | 0.8leading~0.8lagging |
| <b>EPS output data</b>  |                       |
| Rated AC output power   | 4000 VA               |
| Rated AC output voltage   | 230 a.c.V             |
| Rated output current  | 17.5 a.c.A            |
| Rated AC output Frequency   | 50 Hz                 |
| Power factor range  | 0.8leading~0.8lagging |
| <b>Battery data</b>   |                       |
| Battery voltage range   | 42-59 d.c.V           |
| Rated charging and discharging current  | 85 d.c.A              |
| Type of battery   | Lithium / Lead-acid   |
| <b>Others</b>   |                       |
| Safety level  | Class I               |
| Overvoltage category  | PV:II AC:III Others:I |
| Ingress Protection  | IP65                  |
| Operation Ambient Temperature   | -25°C - +60°C         |
| Inverter topology   | Non-isolated          |
| Certificate No  | SAA211107             |
|  |                       |
| X <span style="float: right;">Made in China</span>                                  |                       |

Description of label:

| Hybrid Inverter                        |                        |
|--|------------------------|
| Model name                             | SPH 6000TL BL-UP       |
| <b>PV input data</b>                   |                        |
| Max. PV voltage                        | 550V d.c.V             |
| PV voltage range                       | 120-550 d.c.V          |
| PV Isc                                 | 16.9 d.c.A*2           |
| Max. input current                     | 13.5 d.c.A*2           |
| <b>AC output/input data</b>            |                        |
| Rated output/input power               | 6000/6000W             |
| Rated output apparent power            | 6000VA                 |
| Nominal voltage                        | 230 a.c.V              |
| Rated input / output current           | 27/27 a.c.A            |
| Nominal Frequency                      | 50Hz                   |
| Power factor range                     | 0.8leading~0.8lagging  |
| <b>EPS output data</b>                 |                        |
| Rated output apparent power            | 4000VA                 |
| Rated voltage                          | 230 a.c.V              |
| Rated output current                   | 17.5 a.c.A             |
| Nominal Frequency                      | 50 Hz                  |
| Power factor range                     | 0.8leading~0.8lagging  |
| <b>Battery data</b>                    |                        |
| Battery voltage range                  | 42~59 d.c.V            |
| Rated charging and discharging current | 85 d.c.A               |
| Type of Battery                        | Lithium/Lead-acid      |
| <b>Others</b>                          |                        |
| Safety level                           | Class I                |
| Overvoltage category                   | PV:II AC:III Others: I |
| Ingress protection                     | IP65                   |
| Operation Ambient Temperature          | -25°C~+60°C            |
| Inverter topology                      | Non-isolated           |
| Certificate No                         | SAA211107              |



## 3.3 Size and weight




Chart 3.1

|              | A(mm) | B(mm) | C(mm) | weight(kg) |
|--------------|-------|-------|-------|------------|
| SPH TL BL-UP | 456   | 565   | 188   | 27         |

## 3.4 The advantage of the unit of SPH

Features below:

- All of the designs are designed to enhance the self-use function of photovoltaic energy.
- Smart management, work mode can be set
- Safe battery used
- Easy installation
- Two MPP tracker input
- The switching time between off-grid and grid-connected is less than 10mS
- With multi-machine anti - current parallel function

**Warning**

- ◀ Please check that the package is in good condition before unpacking to ensure that there are no transportation or handling damage that may affect the insulation integrity or safety clearance; Failure to do so could result in a safety hazard.
- ◀ Unauthorized removal of necessary protections, improper use, incorrect installation and operation may lead to serious safety and shock hazards and/or equipment damage.
- ◀ In order to reduce the damage caused by the moving process, please move the inverter correctly. The total weight of the SPH series inverter is up to 27KG.

Please check whether external damage to the goods before unpacking. After unpacking, please check whether the unit damage or missing parts, if it is happen, please contact with supplier.

Growatt SPH series and accessories as follows:




Chart 4.1

| Item | Number | Description                          |
|------|--------|--------------------------------------|
| A    | 1      | SPH inverter                         |
| B    | 1      | User Manual                          |
| C    | 1      | Paper board(installation guide)      |
| D    | 1      | Waterproof cover                     |
| E    | 1      | AC Grid connector                    |
| F    | 1      | EPS output connector                 |
| G    | 1      | Communication cable                  |
| H    | 1      | Current sensor                       |
| I    | 1      | Lead-acid battery temperature sensor |
| J    | 1      | RJ45 connector                       |

# Installation 5

| Item | Number | Description            |
|------|--------|------------------------|
| K    | 4      | M6 setscrew            |
| M    | 2      | Battery power terminal |
| N    | 6      | screw                  |
| O/P  | 2/2    | MC4 connector          |
| Q    | 1      | Hex screwdriver        |

## 5.1 Basic installation requirements

- A. The installation location must be suitable for SPH's weight for a long period time
- B. The installation location must conform with dimension of SPH
- C. Do not install the unit on structures constructed of flammable or thermo labile materials
- D. The ingress Protection rate is IP65 and the pollution degree is PD2. Please refer to the below:




Chart 5.1

- E. Battery installation option is not far away from the position of SPH, the length between SPH and battery should not be more than 1.5m.
- F. The ambient temperature should be  $-25^{\circ}\text{C} \sim 60^{\circ}\text{C}$ .
- G. SPH can be installed in vertical or lean back on plane, please refer to the below:




Chart 5.2

H. Installation position shall not prevent access to the disconnection means.  
 I. In order to ensure machine can run normally and easy to operate, please pay attention to provide adequate space for SPH, please refer to below:




Chart 5.3

- J. Do not install the machine near television antenna or any other antennas and antenna cables
- K. Don't install the machine in the living area
- L. Be sure that the machine is out of the children's reach
- M. Taking the battery fixing space into account, about the dimensions please reference user manual
- N. The inflammable and explosive dangerous goods must not be placed around battery in case of cause serious danger.

## 5.2 Installation requires tools and RJ 45 terminal sequence of the LAN line

When installing, we need to use tools as follow, prepare the follow tools before installing:



Chart 5.4

| No. | Description                      |
|-----|----------------------------------|
| 1   | Press the RJ45 terminal          |
| 2   | Press battery terminal connector |
| 3   | Disconnect PV terminal           |
| 4   | Unscrew nut                      |
| 5   | Unscrew screw                    |
| 6   | Knock explosion bolt             |
| 7   | Drill holes on the wall          |

LAN line RJ45 sequence as follow:




Chart 5.5



Chart 5.6

LAN line 1-8 colors as below:

| PIN   | 1            | 2      | 3           | 4    | 5          | 6     | 7           | 8     |
|-------|--------------|--------|-------------|------|------------|-------|-------------|-------|
| Color | White orange | Orange | White green | Blue | White blue | Green | White brown | Brown |

## 5.3 Installation Instructions

### 5.3.1 Attention Layout (length of sensors consider)

There're two types of sensors for use with SPH. One is wired current sensor, one is meter sensor, if you choose wired sensor or meter. Before installing you should know something that as below:

The cable of wired sensor is suggested not longer than 15m, and the meter is suggested not longer than 100m. So you need to consider the length between SPH with combiner box for the sensor should be installed in the live line.

The layout of the inverter for residential installation as follow:






Chart 5.7 SPH 3000-6000TL BL-UP

### 5.3.2 Installation of SPH

1. Project the machine's probably sizes on the wall, the thickness of wall for SPH must be not less than 60mm.
2. Make sure the drill position, use paper board (installation guide), put the paper board cling to the wall, make sure the top edge of paper board is level (As the chart 5.8a below).
3. Mark four points at the wall via the hole of the paper board, then remove the paper board.
4. Drill four  $\Phi 8$  holes at the mark point, the depth is not less than 55mm.
5. Knock four explosion bolt into  $\Phi 8$  holes (As the chart 5.8b below).
6. Hang the inverter machine on the four setscrews (As the chart 5.8c below).
7. Lock the nut of setscrew (As the chart 5.8d below).
8. The whole installation has finished.




a)



b)

c)



d)  
Chart 5.8

## 5.4 SPH System Connection Mode

### 5.4.1 Conditions for DC Connection



**Warning**

The solar modules connected to the inverter must conform to the Class A requirements of the IEC 61730 standard. Please use the same brand male and female PV connectors.

SPH single-phase inverter has 2 independent input MPPT1 & MPPT2

Notice: 1. that the connectors are in paired (male and female connectors).  
2. in built DC switch isolator is optional in Australia for SPH



**CAUTION**

If the inverter is not equipped with a DC switch but this is mandatory in the country of installation, install an external DC switch. The following limit values at the DC input of the inverter must not be exceeded:

| Types                 | Max current MPPT1 | Max current MPPT2 |
|-----------------------|-------------------|-------------------|
| SPH 3000-6000TL BL-UP | 13.5A             | 13.5A             |

### 5.4.2 Connecting the PV Array (DC input)



**DANGER**

#### Danger to life due to lethal voltages!

The photovoltaic array provides DC voltage to the inverter under light. Before connecting the photovoltaic array, ensure that the DC switch and AC circuit breaker are disconnected from the inverter when adjusting the photovoltaic array. Do not connect or disconnect the DC connector under load.

Make sure the maximum open circuit voltage (Voc) of each PV string is less than the maximum input voltage of the inverter. Check the design of the PV plant. The Max. Open circuit voltage, which can occur at solar panels temperature of -15°C, must not exceed the Max. Input voltage of the inverter.



**CAUTION**

1. Improper operation during the wiring process can cause fatal injury to operator or unrecoverable damage to the inverter. Only qualified personnel can perform the wiring work.
2. Please don't connect PV array positive or negative pole to the ground, it could cause serious damages to the inverter.
3. Check the connection cables of the PV modules for correct polarity and make sure that the maximum input voltage of the inverter is not exceeded.
4. Grounding the PV modules: The SPH is a transformer less inverter. That is why it has no galvanic separation. Do not ground the DC circuits of the PV modules connected to the SPH. Only ground the mounting frame of the PV modules. If you connect grounded PV modules to the SPH, the error message "PV ISO Low".
5. Comply with the local requirements for grounding the PV modules and the PV generator. GROWATT recommends connecting the generator frame and other electrically conductive surfaces in a manner which ensures continuous conduction with ground in order to have optimal protection of the system and personnel.
6. Please disconnect the PV DC switch when maintaining the inverter.

Connection of PV terminal





Chart 5.9

Similar to the traditional inverter connecting, the input of PV panel energy can be realized by using MC4 PV terminal, the detail steps are as follows:

1. Turn off PV switch.
2. Insert PV panel positive and negative cables into MC4 terminal, then connect positive pole(+) of connection cable to positive pole(+) of PV input connector, connect negative pole(-) of connection cable to negative pole(-) of PV input connector, please pay attention to PV input voltage and current within permission Limit:  
 Max PV voltage: 550V (consider the lowest temperature)  
 Max PV input current: 13.5A  
 Max PV input power per string: 5300W

**Remark:**

1. We suggest you use the cable  $\geq 4\text{mm}^2/12$  AWG to connect.
2. Please do not connect to DC source!

**5.4.3 Connection of AC terminal and off grid terminal**

SPH has a grid output terminal and off grid out terminal, look down on the SPH from the front, the terminal on the left (on grid) is grid outlet for connecting grid, the terminal on the right is an emergency power outlet for connecting critical load.




Chart 5.10 SPH 3000-6000TL BL-UP

**Wire suggest length**

| Conductor cross section     | Max cable length |                  |                  |                  |                  |                  |
|-----------------------------|------------------|------------------|------------------|------------------|------------------|------------------|
|                             | SPH 3000TL BL-UP | SPH 3600TL BL-UP | SPH 4000TL BL-UP | SPH 4600TL BL-UP | SPH 5000TL BL-UP | SPH 6000TL BL-UP |
| 5.2mm <sup>2</sup><br>10AWG | 40m              | 33m              | 28m              | 26m              | 25m              | 23m              |
| 6.6mm <sup>2</sup><br>9AWG  | 50m              | 42m              | 36m              | 33m              | 32m              | 29m              |

The AC wiring step:

Step 1. Uninstall the parts of the AC connection plug from the accessory bag.




Chart 5.11

Step 2: Insert the stripped and bared cable through pressure screw, seal ring, threaded sleeve in sequence, insert cables into connection terminal according to polarities indicates on it and tighten the screws firmly. Please try to pull out the wire to make sure the it's well connected.




Chart 5.12

Step 3: Push the threaded sleeve into the socket, Tighten up the cap on the terminal.







Chart 5.13

Step 4: Finally, Push or screw the threaded sleeve to connection terminal until both are locked tightly on the inverter.



Lock the housing  
Chart 5.14

Step5: To remove the AC connector, press the bayonet out of the slot with a small screwdriver and pull it out, or unscrew the threaded sleeve, then pull it out.





Chart 5.15

The recommended wiring diagram is as follows:




Chart 5.16

**Note:** This diagram A is an example for grid system without special requirement on electrical wiring connection.




Chart 5.17

**Note:** This diagram B is an example for Australian and New Zealand grid system where neutral line can't be switched.





Chart 5.18

**Note:** This diagram C is an example for customer who only wants to use the on grid storage system.

|   |  |
|---|--|
|  <p><b>Warning</b></p> | <ul style="list-style-type: none"> <li>&lt; If you want to use on grid only, please refer to chart 5.17 connect with AC grid and float EPS OUTPUT.</li> <li>&lt; If you have no battery now, you can also float BAT terminal, and this hybrid inverter will only work like a PV inverter.</li> <li>&lt; If you want to use both on grid power and backup power, please refer to chart 5.15 and 5.16 connect with AC grid and EPS OUTPUT like the chart show.</li> <li>&lt; On grid terminal and off grid terminal can't directly connect together.</li> <li>&lt; Off Grid terminal can't connect to grid.</li> <li>&lt; If you want to use on grid and off grid, you can use ATS (automatic transfer switch) like chart 5.15 and 5.16 before or ask Growatt for help to connect them.</li> <li>&lt; The first start of system needs Grid power.</li> </ul> <p><b>NOTE:</b> The inverter has the function of detecting residual current and protecting the inverter against residual current. If your inverter must equip a AC breaker which has the function of detecting residual current, you must choose a Type A RCD breaker with the rating residual current more than 300mA.</p> |
|---|--|

#### 5.4.4 Connection of battery terminal

Install battery cable steps are as follows:

1. Unscrew the swivel nut from the cable gland.
2. Thread the swivel nut over the battery cable.
3. Press the cable support sleeve out of the cable gland.
4. Remove the filler plug from the cable support sleeve.
5. Route the network cable through an opening in the cable support sleeve.
6. Thread the network cable through the cable gland.
7. Thread cables into connection terminal, then press the terminal by relevant tools and make sure battery cables are firmly (Growatt lithium battery contains a battery cable in the original packing).
8. Connect positive pole (+) of battery cable to battery positive terminal (+) of the inverter, connect negative pole (-) of battery cable to battery negative terminal (-).
9. Continue to install other cables.




Chart 5.19






Chart 5.20




Chart 5.21

**Note:**We suggest the distance between battery and SPH no longer than 1.5m, and the power line area must be larger than 5 AWG.

#### 5.4.5 Connection of CT terminal

There is a CT in SPH inverter monitoring the power consumption situation of residential users, the CT terminal connection steps are as follows:

1. Unscrew the swivel nut from the cable gland.
2. Thread the swivel nut over the "CT" cable.
3. Press the cable support sleeve out of the cable gland.
4. Remove the filler plug from the cable support sleeve.
5. Route the "CT" cable through an opening in the cable support sleeve.
6. Thread the "CT" cable through the cable gland.
7. Insert the RJ45 plug of the network cable into the "CT1/METER1" pin connector on the inverter until it snaps into place.
8. If no other cables need to be installed, lock the waterproof cover to the inverter with screws.
9. Screw the swivel nut onto the waterproof cover.




Chart 5.22




Chart 5.23

#### Note:

1. The meter and CT can't be installed at same time, please set the sensor model when selecting CT or electricity meter, please refer to section 6.3.3 for details.
2. If the cable such as "CT" cable is not used, please do not remove the filler plug from the cable support sleeve.

#### Remark:

CT wire (5m in length) specification: RJ45, standard LAN line (one end with 8P modular plug, the other connected with transformer). But if the length is not enough, customer can add cable, so the length can be increased to 15m max, the operation is as follow chart:




Chart 5.24

During the actual operation, please pay attention to the installation of current transformer as the diagram shows below:




Chart 5.25

As illustrated above, open the current transformer and you can see an arrow labeled on it indicating the direction of current. Put the live wire among the under-detection wires onto the current transformer. After latching the current transformer, the installation has been finished.

**Notice:**

The direction (from K to L) of the arrow on the current transformer is corresponding to the direction of the current in live wire from Grid to Load. Sensor needs to be placed in the power distribution cabinet.

**5.4.6 Connection of meter terminal**

When customer needs to use meter to monitor the energy flow, the meter terminal connection steps are as follows:

1. Reference 5.2, make LAN cables with RJ45 terminal.
2. Thread the swivel nut over the LAN cable.
3. Press the cable support sleeve out of the cable gland.
4. Remove the filler plug from the cable support sleeve.
5. Route the LAN cable through an opening in the cable support sleeve.
6. Thread the LAN cable through the cable gland.
7. Insert the RJ45 plug of the network cable into the "CT1/METER1" pin connector on the inverter until it snaps into place.
8. If no other cables need to be installed, lock the waterproof cover to the inverter with screws.
9. Screw the swivel nut onto the waterproof cover.





Chart 5.26

**Note:**

1. Meter and CT can't be installed at same time, please set the sensor model when selecting CT or electricity meter, please refer to section 6.3.3 for details.
2. Meter must be provided by Growatt. If not, maybe meter can't communicate with SPH inverter.
3. The more detail describe of meter installation, please turn to meter user manual.

|  |  |
|--|--|
| <br>Information | The position of export limitation CT or Meter must between the Inverter & Load and grid. |
|--|--|

This series inverter has integrated export limitation functionality. To use this function, you can connect smart meter or CT. The smart meter model is Eastron SDM120CT-M (40mA). The CT Model is ESC 16-100 (ECHUN)/ CTF16-2K5-100 (Shenke). The primary aperture is 10mm, output cable length is 5m. The arrow on the CT must point towards the inverter. The detailed information about the Meter, please refer to Annex -Eastron SDM120CT-M (40mA) user manual. (Can also match Chint DSSU666 direct connection meter)

**SDM120CT-M(40mA) datasheet**

|              |                  |
|--------------|------------------|
| Manufacturer | Eastron          |
| Type         | SDM120CT-M(40mA) |

**General Specifications**

|                           |   |
|---------------------------|---|
| Voltage AC (Un)           | 230V  |
| Voltage Range             | 176~276V AC   |
| Base Current (Ib)         | 0.1V AC   |
| Power consumption         | <2W/10VA  |
| Frequency                 | 50/ 60Hz(±10%)                                      |
| AC voltage withstand      | 4KV for 1 minute                                    |
| Impulse voltage withstand | 6KV-1.2uS waveform                                  |
| Over current withstand    | 20Imax for 0.5s                                     |
| Pulse output 1            | 1000imp/kWh (default)                               |
| Pulse output 2            | 0.001(default) /0.01/0.1/1 kWh/kVArh (configurable) |
| Display Max. Reading      | LCD with white backlit 999999kWh                    |

**Environment**

|  |                          |
|--|--------------------------|
| Operating temperature                  | -25°C to +55°C           |
| Storage and transportation temperature | -40°C to +70°C           |
| Reference temperature                  | 23°C ± 2°C               |
| Relative humidity                      | 0 to 95%, non-condensing |
| Altitude                               | up to 2000m              |
| Warm up time                           | 3s                       |
| Installation category                  | CAT II                   |
| Mechanical Environment                 | M1                       |
| Electromagnetic environment            | E2                       |
| Degree of pollution                    | 2                        |

## Mechanics

|                     |                             |
|---------------------|-----------------------------|
| Din rail dimensions | 18x118x64 (WxHxD) DIN 43880 |
| Mounting            | DIN rail 35mm               |
| Ingress protection  | IP51 (indoor)               |
| Material            | self-extinguishing UL94V-0  |




Chart 5.27

The following table describes how we can connect EASTRON meter SDM120CT(40mA) to inverter:

| Meter Pin NO. | Description | Meter Connection    |
|---------------|-------------|---------------------|
| 1             | CT-input    | CT-P(White)         |
| 2             |             | CT-N(Black or Blue) |
| 3             | N-in        | Grid N              |
| 4             | L-in        | Grid L              |
| 5             | RS485B      | Meter Port Pin4     |
| 6             | RS485A      | Meter Port Pin5     |

### 5.4.7 Connection of communication terminal for lithium battery (CAN)

When using CAN communication with lithium batteries (for example ARK LV Battery), connect lithium battery terminal (RJ45) steps as follows:

1. Unscrew the swivel nut from the cable gland.
2. Thread the swivel nut over the "CAN" cable.
3. Press the cable support sleeve out of the cable gland.
4. Remove the filler plug from the cable support sleeve.
5. Route the "CAN" cable through an opening in the cable support sleeve.
6. Thread the "CAN" cable through the cable gland.
7. Insert the RJ45 plug of the network cable into the "CAN" pin connector on the inverter until it snaps into place.
8. If no other cables need to be installed, lock the waterproof cover to the inverter with screws.
9. Screw the swivel nut onto the waterproof cover.




Chart 5.28




Chart 5.29

#### Note:

1. If you are using a lead-acid battery, you do not need to install this communication cable.
2. The CAN battery communication and 485-2 battery communication can't be installed at the same time, please select the correct communication method according to the battery manual.
3. If the cable such as "485-2" cable or "CAN" cable is not used, please do not remove the filler plug from the cable support sleeve.

#### 5.4.8 Connection of communication terminal for lithium battery (RS485)

When using lithium batteries which need to connect BMS system of the battery, connect lithium battery terminal (RJ45) steps as follows:

1. Unscrew the swivel nut from the cable gland.
2. Thread the swivel nut over the "RS485" cable.
3. Press the cable support sleeve out of the cable gland.
4. Remove the filler plug from the cable support sleeve.
5. Route the "RS485" cable through an opening in the cable support sleeve.
6. Thread the "RS485" cable through the cable gland.
7. Insert the RJ45 plug of the network cable into the "RS485-2" pin connector on the inverter until it snaps into place.
8. If no other cables need to be installed, lock the waterproof cover to the inverter with screws.
9. Screw the swivel nut onto the waterproof cover.




Chart 5.30

Chart 5.31

#### Note:

1. If you are using a lead-acid battery, you do not need to install this communication cable.
2. The CAN battery communication and 485-2 battery communication can't be installed at same time, please select the correct communication method according to the battery manual.
3. If the cable such as "485-2" cable or "CAN" cable is not used, please do not remove the filler plug from the cable support sleeve.

#### 5.4.9 Connection of DRMS terminal (Australia only)

When SPH is applied in Australia, the DRMS terminal needs to be connected. The connection method is as follows:

1. Unscrew the swivel nut from the cable gland.
2. Thread the swivel nut over the "DRMS" cable.
3. Press the cable support sleeve out of the cable gland.
4. Remove the filler plug from the cable support sleeve.
5. Route the "DRMS" cable through an opening in the cable support sleeve.
6. Thread the "DRMS" cable through the cable gland.
7. Insert the RJ45 plug of the network cable into the "DRM" pin connector on the inverter until it snaps into place.
8. If no other cables need to be installed, lock the waterproof cover to the inverter with screws.
9. Screw the swivel nut onto the waterproof cover.




Chart 5.32

Chart 5.33

|     |   |
|-----|---|
| PIN | Inverter distribution capable of charging and discharging at the same time. |
| 1   | DRM5  |
| 2   | DRM6  |
| 3   | DRM7  |
| 4   | DRM8  |
| 5   | RefGen  |
| 6   | COM/DRM0  |
| 7   | /   |
| 8   | /   |

Method of asserting demand response modes

| MODE | RJ45 socket asserted by shorting pins |   | Requirement  |
|------|---------------------------------------|---|--|
| DRM0 | 5                                     | 6 | operate the disconnection device   |
| DRM5 | 1                                     | 5 | Do not generate power  |
| DRM6 | 2                                     | 5 | Do not generate at more than 50% of rated power                                    |
| DRM7 | 3                                     | 5 | Do not generate at more than 75% of rated power and sink reactive power if capable |
| DRM8 | 4                                     | 5 | Increase power generation (subject to constraints from other active DRMs)          |

**Note:**

If the cable such as "NTC" (lead-acid battery temperature sensor) cable is not used, please do not remove the filler plug from the cable support sleeve.

**5.4.10 Connection of temperature probe for lead-acid battery**

When customer using lead-acid battery, the temperature probe of the lead-acid battery is used to detect the ambient temperature of the lead-acid battery, the battery temperature cable of the SPH side connection steps are as follows:

1. Unscrew the swivel nut from the cable gland.
2. Thread the swivel nut over the "NTC" cable.
3. Press the cable support sleeve out of the cable gland.
4. Remove the filler plug from the cable support sleeve.
5. Route the "NTC" cable through a min opening in the cable support sleeve.
6. Thread the "NTC" cable through the cable gland.
7. Insert the RJ45 plug of the network cable into the "NTC" pin connector on the inverter until it snaps into place.
8. If no other cables need to be installed, lock the waterproof cover to the inverter with screws.
9. Screw the swivel nut onto the waterproof cover.




Chart 5.34




Chart 5.35

**Note:**

1. If you are using a lithium battery, you do not need to install this temperature probe, the probe of the temperature cable should be attached to the surrounding environment of the lead-acid battery, and the length of this cable is 1.5m, so pay attention to the distance of battery and SPH.
2. If the cable such as "NTC" (lead-acid battery temperature sensor) cable is not used, please do not remove the filler plug from the cable support sleeve.

#### 5.4.11 Connection of Dry contact

The dry contact is used to communicate with external devices (such as remote start hot water heater). The wiring steps are as follows:

1. Unscrew the swivel nut from the cable gland.
2. Thread the swivel nut over the cable.
3. Press the cable support sleeve out of the cable gland.
4. Remove the filler plug from the cable support sleeve.
5. Route the network cable through an opening in the cable support sleeve.
6. Thread the network cable through the cable gland.
7. Thread cables into connection terminal of the inverter, then press the terminal by relevant tools and make sure cables are firmly.
8. If no other cables need to be installed, lock the waterproof cover to the inverter with screws.
9. Screw the swivel nut onto the waterproof cover.




Chart 5.36




Chart 5.37

**Note:**

If the cable such as "Dry contact" cable is not used, please do not remove the filler plug from the cable support sleeve.

#### 5.4.12 Grounding connection

SPH must be grounded by cable, the grounding point is showed as follow, and the minimum grounding cable wire diameter is 10.0mm<sup>2</sup>.




Chart 5.38

**PV Array Grounding**

Grounding conductor of PV panel brackets must be firmly connected to earth at PV array side and inverter side and SP side. The sectional area of grounding conductor should be equal to the sectional area of DC grounding conductor. The minimum wire diameter is 10.0mm<sup>2</sup>.

**DC Grounding**

Select the DC Grounding mode according to the local standard and use the PV grounding terminal box and DC Grounding wires of the same specification.

**Grounding Device**

If the positive pole or the negative pole of PV array needs to be grounded in the PV system, the inverter output should be insulated by Isolation Transformer. Isolation transformer must conform to IEC62109-1,-2 standard.

Connection as below:




Chart 5.39



**Warning**

1. Growatt SPH &SPH TL BL-UP series inverters are all single-phase inverters, If the inverter is installed in Australia or New Zealand the inverter must not be used as part of a three-phase combination
  2. This inverter complies with IEC 62109-2 clause 13.9 for earth fault alarm monitoring.
- If an Earth Fault Alarm occurs, the fault code "Error303,NE abnormal" will be displayed on the inverter screen while the LED indicator red will light up. (Applicable to inverters with graphical display only)

# 6 Commissioning

## 6.1 Commissioning of SPH

Electrify SPH after all installation of Part5 be finished, here are the steps:

- 1.Connect PV
- 2.Connect AC
- 3.Connect battery
- 4.Turn on AC first
- 5.Then turn on battery
- 6.Last turn on PV

If PV Grid and battery are available, system would work on the "normal" mode. When SPH works normally, the screen displays "normal" and the LED is green. If SPH not enter normal mode successful, especially the LCD is red, you need to check below:

- 1.Make sure all the connection is correct.
- 2.All the external switches are on.
- 3.Inverter built -in switch is on.
- 4.Make sure the lithium battery is on.
- 5.Refer to Part 9.1 for correction.

You can refer to Part 6.3.4 for work mode setting, then configure monitor, finish commissioning lastly.

## 6.2 Operation modes

### 6.2.1 Normal mode

Normal mode is working state which including online mode and backup mode.

#### Online mode

User can set an appropriate priority mode according to request when SPH working on the online mode. If customer uses the LCD and key settings, you can only set one period, but if you use website settings, you can set up to three periods of the priority mode. (refer to 6.3.4)

1. Load first: Load first is the default mode, when it's working in this mode, PV energy would offer to load and battery prior; when PV is Insufficient, battery would discharge; when PV is sufficient for load, the excess energy would feed to battery. If there is no battery or battery is full, the excess energy would feed to Grid (If the export limit function is enabled, the excess PV energy will not be sent to the power grid).

2. Battery first: When SPH working in this mode, battery would be charged first, it's suitable working on the period when the electric charge is low. user need to set the mode ON and OFF time, and the end time of battery SOC. Users can set power rate which less than the battery maximum output power. If the customer doesn't enable the AC CHG (AC grid charging functions). Inverter will charge battery by PV power as large as it can do. If the customer enables the AC CHG (AC grid charging functions). Inverter will charge battery by PV power and AC power from grid as large as it can do.

3. Grid first: When SPH working in Grid-first mode, the PV energy would feed to Grid first. User can choose the period when electric charge is high. User need to set the mode ON and OFF time, and the end time of battery SOC. User can set power rate which less than the battery maximum output power.

### Backup mode

If Grid is lost, system would switch to backup mode (user can disable this function, refer to 6.3.4) and AC output is supplied via the EPS LOAD port using energy from PV and battery. If the PV is also lost, then only the battery discharges.

Note: SPH EPS LOAD maximum output power is 4000W so loads connected to the EPS LOAD port should not exceed 4000W.

#### Notice:

- 1.Users only can set one period for battery first and Grid first on the LCD, if users need set more please login shineserver.
- 2.If users need Grid charge battery, users need input password on the SC surface and set the AC CHG to enable.

### 6.2.2 Fault mode

The SPH's intelligent control system could monitor and adjustment system's status continuously, when SPH inverter monitoring anything unexpected happen, such as system fault or machine fault ,the LCD will display the fault information, in fault mode, the LED light will be lighten.

#### Notice:

- 1.The detail's fault information please refer to 9.1
- 2.Some fault information is in order to remind users that might have some faults occurred in inverter side.

### 6.2.3 Programming mode

Programming mode indicates the SPH is updating, don't cut out power when it's updating until the processing is finish, SPH inverter would log out automatically when the updating finish and turn to other mode.

### 6.2.4 Checking mode

Before SPH work in normal mode, it will go to self-check mode. If all are ok, system will go to normal mode, otherwise, it will go to fault mode.

### 6.2.5 Standby mode

If the system hasn't faults while the condition is not qualified, SPH would stay at standby mode.

### 6.2.6 Shutdown mode

If customer need SPH inverter stop working, customer must disconnect all the energy source, then SPH inverter will turn into shutdown mode automatically.

The following is the shutdown procedure:

- 1.Shutdown the PV side
- 2.Turn off battery switch.
- 3.Shut down AC power of SPH. Then you can see the both LED and LCD of SP are off.

#### Notice:

After all the actions are done, you still have to wait for more than 5 minutes.

## 6.3 Display and button

### 6.3.1 LCD display area




Chart 6.1

| Location | Description  |
|----------|--|
| A        | State  |
| B        | Information  |
| C        | PV input (If you connect two tracks, it will show two. Otherwise show one) |
| D        | SPH inverter   |
| E        | Power flow line  |
| F        | Grid   |
| G        | Battery (Show the SOC in five grid, Every grid represents 20%)             |
| H        | Local load   |
| I        | Wireless communication   |
| J        | RS232  |
| K        | RS485  |
| L        | Buzzer(Reserved)   |
| M        | Warning  |
| N        | Fault  |

### 6.3.2 LED and button instruction




Chart 6.2

| Location | Description                 |
|----------|-----------------------------|
| A        | Status                      |
| B        | ESC- button(cancel control) |
| C        | Down-button                 |
| D        | Enter-button                |
| E        | UP-button                   |

#### Notice:

LED showing status of SPH, it has two colors, one is green and another is red. Please turn to 3.1 and read the detail of LED

### 6.3.3 LCD display column

Grovet can provide a variety of rules and regulations of the machine, the customer received the machine, according to their country, through the LCD selection to set the corresponding rules and regulations.




Chart 6.3



The A line's concluding information as follow:

- 1.Standby state: SPH is in standby state. No error in this state, but for other reasons make it in a wait state.
- 2.Normal state: SPH is normal working state.
- 3.Checking state: SPH is in self-check state, if there is no error or warning, SPH will go to normal state or standby state. Otherwise it will go to fault state.
- 4.Programming state: SPH is in updating firmware state.
- 5.Fault state: SPH has fault information, it will be in stopped operational protection state.

The B line's information as follow:

In normal, it will turn on page automatically, when pushing the button "UP", the order of the paging information as follow:




Chart 6.4

Note:

- 1."Down" control command (if pushing "up" button, command will go back).
- 2.Work mode depend on the situation. If SPH is normal state, it will show "normal". If SPH is standby state, it will show as "standby" etc.
- 3.Some special definitions are explained, for example: Vb means the voltage of battery. Cb means the capacity of lithium battery (only lithium battery shows this data). Pm means the monitor power of user.

### 6.3.4 Work mode set up

Keep pressing "enter" for 3S, you can enter set up surface, in the set up surface you need hold button Enter or ESC 1S for selection, you can see the surface as showing below.




Chart 6.5

If you choose CEI and used SPH inverter in Italy, SPH inverter have Auto Test function. How to use the Auto test functions. Please see the annex.

1. Under the Basic Para, you can see the setup options below after pressing Enter for 1S:




Chart 6.6

In the basic Parameter, you can set language (English, Italian, German), system time, lead-acid cell charging voltage (default is 58V), discharge low voltage (default is 48V) and lead-acid constant current (default is 60A).

2. Under the Back Up, you can see the setup options below after pressing Enter for 1S:




Chart 6.7

In the back up you can set EPS, including enable or disable (default is enable), AC voltage (default is 230V) and frequency (default site 50HZ).

1. Under the Priority, you can see the setup options below after pressing Enter:




Chart 6.8

Note:

1. "Power Rate" is used to set up power of battery. So different battery may have the different power, customer need to check the max power of battery.
2. Time setting is 24-hour. If the end time is less than beginning time, it defaults to spanning days.
3. Under the MODE Change, you can see the setup options below after pressing Enter:




Chart 6.9

The MODE change has two options what are sensor and battery type, sensor is cable CT (default), meter and SP-CT (wireless RF transfer). In the battery type, you can choose lithium battery or lead-acid battery.

4. Under the Export Limit, you can see the setup options below after pressing Enter:




Chart 6.10

Export limit is used for users to control the energy flowing to the grid. If this function is enabled, the feeding power to grid will be equal or less than the setup value. The purpose of the Fail Safe function is to ensure that should any part of the ELS fail, the Active Power exported across the Connection Point will drop to the Agreed Export Capacity or less within the specified time.

Note: 1. Default value is 00.0%  
Fail safe works only in meter mode

5. Under the default set, you can see the setup options below after pressing Enter:



Chart 6.11

Default set is "resume to default setting", please don't use it unless it's necessary.

## 6.4 Communication

### 6.4.1 Use of USB-A port

USB-A port is mainly for firmware update. Through USB connection, we can quickly update the software of machine. You can see USB-A as below:




Chart 6.12

Note:  
USB is only used for firmware update. Customer can't use it for charging.

### 6.4.2 The SPH's monitoring

Users can through the following communication solution to monitor the SPH.

Note:  
This monitoring can only be used by Growatt's Shine server/Shine phone's monitor provided by the company. Wi-fi -X/ Shine Link-X through USB interface, using computer terminal/mobile phone for data monitoring.




Chart 6.13

The USB collector is connected:




Chart 6.14

Whether it is a Wi-Fi-X/ Shine link-x collector; Connect to the remote monitoring system, scan the QR code on the collector to download the APP. After the download is complete, please prompt for operation. Please see the collector manual for details.

## 6.5 Country setting

### 6.5.1 section describes how to set national security specifications

Growatt offers machines in a variety of specifications. For the SPH TL BL-UP series, the specifications specified by the national safety regulations are set directly on the LCD, without the need for the dip switch.

**Note:** For compliance with AS/NZS 4777.2:2020, installers will need to select country using instructions in Section 6.5.3 or 6.5.4 and then select Region A, B, or C using instructions in Section 6.5.7.

### 6.5.2 Method for setting national security standards for SPH 3000-6000TL BL-UP series models:

Single point down button toggle display or up button Click the "OK" key to confirm the Settings.






Chart 6.15

|  |  |
|--|--|
|  <p><b>DANGER</b></p> | <p>Caution :<br/>When setting national safety standards for the LCD, turn off the PV switch and AC breaker, but turn on the battery power.</p>   |
|                       | <p>Caution:<br/>You need to calibrate the time that the machine is showing after inverter starts up.<br/>If the country is set incorrectly, please shut down the inverter and set again.</p> |

### 6.5.3 Switch to country table

| Country/region / regulations | Model display | Country/region / regulations | Model display |
|------------------------------|---------------|------------------------------|---------------|
| VDE 0126                     | GT0XXXXXX1    | Danmark-EN50438-1            | GT0XXXXXXB    |
| Queensland                   | GT0XXXXXX2    | Hungary                      | GT0XXXXXXC    |
| AS4777                       | GT0XXXXXX3    | Belgium                      | GT0XXXXXXD    |
| CEI 0-21                     | GT0XXXXXX4    | Thailand MEA                 | GT0XXXXXXE    |
| G99                          | GT0XXXXXX5    | Thailand PEA                 | GT0XXXXXXF    |
| XINA1                        | GT0XXXXXX6    | Sp1663                       | GT1XXXXXX0    |
| VDE-AR-N 4105                | GT0XXXXXX7    | CQC-1                        | GT1XXXXXX1    |
| G98                          | GT0XXXXXX8    | TAIWAN                       | GT1XXXXXX2    |
| Norway-EN50438               | GT0XXXXXX9    | EN50438-Ireland              | GT1XXXXXX3    |
| CQC                          | GT0XXXXXXA    | TUV000                       | GT1XXXXXX4    |

### 6.5.4 Regional power grid setting

Note: This section is for compliance to AS/NZS 4777.2:2015 only

Growatt noticed the Volt-Watt and Volt-Var settings will become mandatory for some of DNSP from 1<sup>st</sup> December.


2019 in Australia. All the Growatt inverters have capability to meet the different Volt-Watt and Volt-Var settings.

Based on CEC notification, SA power network, Horizon Power, Western Power, EnergyX, Ergon energy, Ausnet Services, Essential Energy, Jemena, Citipower, Powercor, Ausgrid and Endeavour will have their own settings.

#### Steps of Country/Area setting in Growatt SPH models

Step1: Please configure Country/ Area follow the table below

| Country/Area  | Model display  | Country/Area | Model display |
|---------------|--|--------------|---------------|
| Australia     | GT4XXXXXX3   | Ausgrid      | GT4XXXXXX6    |
| Queensland    | GT4XXXXXX2   | Endeavour    | GT4XXXXXX7    |
| Victoria      | GT4XXXXXX1   | Ergon Energy | GT4XXXXXX8    |
|               | GT4XXXXXX4   | Energex      | GT4XXXXXX9    |
| Horizon Power | GT4XXXXXX5   | SA Network   | GT4XXXXXXA    |
| New Zealand   | GT5XXXXXX8   |              |               |
|               | Step2: Turn on the AC switch between the SPH inverter and the power grid.<br>Step3: Turn on the AC switch of SPH inverter (both AC and battery are turned on, if there is no battery, only AC is turned on), and the inverter starts automatically.<br>Step4: Make sure the inverter is connected to Internet and staying online in the Shine Phone APP. |              |               |



**WARNING**

1. Once the power quality and grid Settings have been selected during debugging, these Settings should be locked and cannot be edited (unless they can be changed by Growatt authorization password).
2. After setting the power quality and power grid, you can check whether the safety regulations are correct through the mobile APP.
3. When the Country setting is complete, we need to select the right Power Quality Response Mode, if we don't select any mode, the inverter will run under default mode different from region.

#### 6.5.4 Check firmware version, Region, Country/Area and Power Quality Response Modes




Chart 6.16

#### 6.5.4 Check firmware version, Region, Country/Area and Power Quality Response Modes

Single point down button toggle display or up button  
Click the "OK" key to confirm the Settings.  
Enter the correct password to change the country/region, region, and PQRM Settings.

##### Reset Country




Chart 6.17

##### Reset Region




Chart 6.18

##### Reset PQRM




Chart 6.19

**Note:** If dnsp needs setpoints other than the default values, please refer to the attachment:  
adjust the setpoints from the regional default values instruction.

# 7 Start-up and shut down SPH system

## 7.1 Start-up the SPH system

Users can start-up SPH inverters through following steps:

- 1.Connect to PV.
- 2.Connect to Grid.
- 3.Connect to Battery.
- 4.Turn the switch on in turn of Grid, battery and PV.
- 5.When the LED turns green, the working information on LCD indicates the successful start-up of SPH inverter.

## 7.2 Disconnect the SPH system

- 1.Turn off all the circuit breaker and switch
- 2.Disconnect PV
- 3.Disconnect the inverter
- 4.Disconnect the battery
- 5.Pull up AC PLUG connection
- 6.Waiting until LED, LCD display have gone out, the SPH is shut down completely

## 7.3 Export limitation and Power Sensor setting




Chart 7.1

Under the permission given by your energy provider, the ratio of your system output power divided by the rated power of the inverter is called Export Limit Rate. For instance, if the energy provider only accepts 4kW from your 5kW system, then the Export Limit Rate of 5kW inverter is 80.0%.

# Attention of the installation environment, maintenance and cleaning

Heat dissipation performance is very important when SPH inverter work under the environment of high temperature, better heat dissipation can reduce the possibility of SPH inverter stops working. Growatt SPH series inverter without fan so belongs to natural cooling, hot air from the top of the radiator, tie-in battery, use environment for IP65, please pay attention to the temperature of the installation environment, to ensure that the battery's safety and the normal work of the machine.

When use battery, please pay attention to the follow information:

Caution: Do not dispose of batteries in a fire. The batteries may explode.

Caution: Do not open or damage batteries. Released electrolyte is harmful to the skin and eyes. It may be toxic.

Caution: A battery can present a risk of electrical shock and high short-circuit current.


The following precautions should be observed when working on batteries:

- Remove watches, rings or other metal objects.
- Use tools with insulated handles.
- Wear rubber gloves and boots.
- Do not lay tools or metal parts on top of batteries.
- Disconnect charging source prior to connecting or disconnecting battery terminals.
- Determine if battery is inadvertently grounded. If inadvertently grounded, remove source from ground. Contact with any part of a grounded battery can result in electrical shock. The likelihood of such shock can be reduced if such grounds are removed during installation and maintenance (applicable to equipment and remote battery supplies not having a grounded supply circuit).

If SPH inverter doesn't work for overheating or too cold, solve it according to the following methods.

- Confirm whether the radiator air duct installation be reasonable, choose the appropriate position before installation.
  - If lead-acid batteries are connected, confirming the NTC battery is in a good installation.
  - Confirm whether the battery temperature is too high, too high temperature of battery can also lead to SPH fail to work, at this point, to ventilation, cooling or still handle to the battery, please.
  - If temperature is low, also can appear the battery low temperature protection, the battery will start with small load in low temperature output, after temperature back to normal system can work normally, please be patient at this time.
  - If the temperature is too low, it is possible that battery will be low temperature protection, at this time, please pay attention to the working temperature range listed in the specifications of the book.
  - Servicing of batteries should be performed or supervised by personnel knowledgeable about batteries and the required precautions.
  - When replacing batteries, replace with the same type and number of batteries or battery packs.
  - General instructions regarding removal and installation of batteries.
- In order to protect the safety of the operation of the system, the inverter needs to be regularly maintained and cleaned as follows.
- Check whether the grounding wire is loose.
  - Whether the terminals are loose.
  - Keep the metal housing of the inverter clean.

# Fault removal 9

|   |   |
|---|---|
| <br><b>WARNING</b> | <p>Remark:</p> <ol style="list-style-type: none"> <li>1. Prior to removal of any cover for maintenance or repair, turn off the switch on the AC and DC sides.</li> <li>2. All of above action should be operated by professional person, if you want to do these works, you must make sure the whole system are off.</li> </ol> |
|---|---|

## 9.1 Troubleshooting method when a fault occurs

Our products are carried out with strict tests before they take out, if the operation difficulties in the process of installation, please log on to [www.ginverter.com](http://www.ginverter.com) website, view the Q&A program.

When SPH inverter fault happens, please inform our company, and to provide SPH related information, we will have a professional after-sales service personnel to answer you.

What you need to provide the information about the SPH including:

- Serial number
- Model
- Information about the LCD display
- Brief description of problems
- The battery voltage
- The PV input voltage and power per string.
- The grid voltage and frequency
- Can you retell the failure problem? If you can, what kind of a situation
- Did the problem happen in the past?
- When did this fault happen? First installation?
- About the battery
- The manufacturer name and model of battery
- Capacity of battery
- Output voltage of the battery
- The time you buy Battery and frequency you use it

## 9.2 System fault information list and troubleshooting suggestions

| Warning Message |   |  |
|-----------------|---|--|
| Error Message   | Description   | Suggestion   |
| Warning 401     | SP-CT/Meter Communication fault   | <ol style="list-style-type: none"> <li>1. Check the wire connection between meter and inverter is good or not.</li> <li>2. Check the distance of SP-CT and inverter is in the range of specification or not.</li> <li>3. Restart inverter and SP-CT, reconnect.</li> </ol> |
| Warning 203     | PV1 or PV2 Circuit short  | <ol style="list-style-type: none"> <li>1. Check the positive and negative of PV input is reversed or not.</li> <li>2. Reinserted the PV terminal, please contact Growatt service center if restart can't solve the problem.</li> </ol>                                     |
| Warning 506     | Battery temperature out of specified range for charge or discharge                                  | <ol style="list-style-type: none"> <li>1. Check the environment temperature of battery is in the range of specification or not.</li> </ol>   |
| AC V Outrange   | Grid voltage fault. Please refer to the local grid standard for more details of the grid frequency. | <ol style="list-style-type: none"> <li>1. Check the AC voltage is in the range of standard voltage in specification.</li> <li>2. Check the grid connection is good or not.</li> </ol>  |

| Error Message    | Description   | Suggestion  |
|------------------|---|---|
| AC F Outrange    | Grid frequency fault. Please refer to the local grid standard for more details for the grid voltage.                                | 1.Check the frequency is in the range of specification or not.<br>2.Restart inverter.<br>3.contact Growatt service center if restart can't solve the problem. |
| PairingTimeOut   | Communication fault   | 1.Check the distance of SP-CT and inverter is in the range of specification or not.<br>2.Restart inverter and SP-CT, reconnect.                               |
| CT LN Reversed   | LN Reversed   | 1.Check the L line and N line of SP-CT is reversed or not.<br>2. Check the PE of SP-CT is connected well or not.  |
| BMS COM Fault    | Communication fault   | 1.Check the lithium Battery is open or not.<br>2.Check the connection of lithium Battery and inverter is good or not.   |
| Battery reversed | Battery terminals reversed  | 1.Check the positive and negative of battery is reversed or not.  |
| BAT NTC Open     | NTC open (only for lead-acid battery)   | 1.Check the temperature of lead-acid battery is installed or not.<br>2. Check the temperature of lead-acid battery is connected well or not.                  |
| Battery Open     | Battery terminal open (only for lithium battery)  | 1.Check the battery connection is good or not.<br>2.Check the switches between the battery and inverter are all on or not.                                    |
| Over Load        | EPS output overload warning. If this warning occurred three time. Off-grid function will be locked one hour and output power again. | 1.Please reduce the load of EPS output.   |
| No AC Connection | No Utility  | 1.Please confirm grid is lost or not.<br>2.Check the grid connection is good or not.<br>3.Check the switches on the cable are on or not.                      |
| Output High DCI  | Output DC current too high. Please refer to the local grid standard for disconnection time when the output DC current is too high.  | 1.Restart inverter.<br>2.Please contact Growatt service center if restart can't solve the problem.  |

| Error Message    | Description                     | Suggestion   |
|------------------|---------------------------------|--|
| Bat Voltage High | Battery Voltage higher than 60V | 1.Check the voltage of battery is in the range of specification or not.<br>2.Check the battery connection is right or not<br>If battery is really higher than 60V. Please disconnect the connection of battery and check inverter. |
| Bat Voltage Low  | Battery Voltage Lower than 42 V | 1.Check the real voltage of battery.<br>2.Check the wire of battery and inverter is good or not.   |
| BMS Warning:XXX  | BMS report warning              | 1.Check the warning information from lithium battery user manual.<br>2.Please contact Growatt service center if restart can't solve the problem.   |
| BMS error:XXX    | BMS report error                | 1.Check the warning information from lithium battery user manual.<br>2.Please contact Growatt service center if restart can't solve the problem.   |
| EPS Volt Low     | EPS output voltage low          | 1.Check the load of EPS. If overload occurred, reduce load.<br>2.Restart inverter again.   |

| Error Message |   |  |
|---------------|---|--|
| Error Message | Description   | Suggestion   |
| Error 411     | Internal communication failed                       | 1.Restart inverter.<br>2.Please contact Growatt service center if restart can't solve the problem. |
| Error 417     | Sample fault  | 1.Restart inverter.<br>2.Please contact Growatt service center if restart can't solve the problem. |
| Error 418     | DSP and COM firmware version unmatch, system fault. | 1.Read DSP and COM firmware version from LCD or shinebus.<br>2.Check if the firmware is correct.   |
| Error 303     | Inverter L N reversed or ground failed              | 1.Check the L line and N line is reversed or not.<br>2.Check the PE s connected well or not.       |
| Error 405     | Relay fault   | 1.Restart inverter.<br>2.Please contact Growatt service center if restart can't solve the problem. |



# Manufacturer Warranty 10

| Error Message    | Description                              | Suggestion  |
|------------------|--|---|
| Error 123        | Autotest failed (only in Italy)          | 1.Restart inverter.<br>2.Please contact Growatt service center if restart can't solve the problem.                                |
| PV Isolation Low | PV isolation too low                     | 1.Check the connection of PV panels and<br>2.inverter is good or not.<br>Check the PE of inverter is good or not.                 |
| OP Short Fault!  | EPS Output Short Fault                   | 1.Check the load of EPS.<br>2.Check the output of EPS. Especial not connect to grid   |
| NTC Open         | Internal temperature failed              | 1.Please contact Growatt service center   |
| Error 406        | Model set up not meet with certification | 1.Please check model set or check the DIP setting   |
| Residual I High  | Leakage current too high                 | 1.Check the cable of inverter.<br>Restart inverter.<br>2.Please contact Growatt service center if restart can't solve the problem |
| Error 408        | Temperature over range                   | 1.Please check the temperature is in the range of specification or not.   |
| PV Voltage High  | PV voltage higher than datasheet         | 1.Please check the voltage of PV input is in the range of specification or not.   |

This certificate represents a 5 year warranty for the Growatt products listed below. Possession of this certificate validates a standard factory warranty of 5 years from the date of purchase.

## Warranted products

This warranty is applicable solely to the following products:

- SPH 3000TL BL-UP
- SPH 3600TL BL-UP
- SPH 4000TL BL-UP
- SPH 4600TL BL-UP
- SPH 5000TL BL-UP
- SPH 6000TL BL-UP

## Limited Product Warranty

(for normal application, installation, use and service conditions) Growatt warrants that the Products will be free from defects and/or malfunctions for a period of 5 or 10 years not exceeding the date of sale as indicated in the original Buyer's Certificate of Purchase.(5 or 10 years is optional)

The warranties described in these "Limited Warranty" are exclusive and are expressly in lieu of and exclude all other warranties, whether written, oral, expresser implied, including but not limited to, warranties of merchantability and of fitness for a particular purpose, use, or application, and all other obligations or liabilities on the part of GROWATT, unless such other obligations or liabilities are expressly agreed to it in writing signed and approved by GROWATT, GROWATT shall have no responsibility or liability whatsoever for damage or injury to persons or property, or for other loss or injury resulting from any cause whatsoever arising out of or related to the modules, including, without limitation, any defects in the modules or from use or installation. Under no circumstances shall GROWATT be liable for incidental, consequential or special damages howsoever caused; loss of use, loss of production, loss of revenues are therefore specifically and without limitation excluded to the extent legally permissible, GROWATT's aggregate liability, if any, in damages or otherwise, shall not exceed the invoice as paid by the customer.

The "Limited Product Warranty" described above shall not apply to, and Growatt shall have no obligation of any kind whatsoever with respect to, any machine which has been subjected to:

- Misuse, abuse, neglect or accident;
- Alteration, improper installation or application;
- Unauthorized modification or attempted repairs;Insufficient ventilation of the product;
- Transport damage;
- Breaking of the original manufacturers seal;
- Non-observance of Growatt installation and maintenance instruction;
- Failure to observe the applicable safety regulations
- Power failure surges, lighting, flood, fire, exposure to incorrect use, negligence, accident, force majeure, explosion, terrorist act, vandalism or damage caused by incorrect installation, modification or extreme weather conditions or other circumstances not reasonably attributable to Growatt.

The warranty shall also cease to apply if the product cannot be correctly identified as the product of Growatt. Warranty claims will not be honored if the type of serial number on the machines have been altered, removed or rendered illegible.

# Decommissioning 11

## Liability

The liability of Growatt in respect of any defects in its machines shall be limited to compliance with the obligations as stated in these terms and conditions of warranty. Maximum liability shall be limited to the sale price of the product. Growatt shall accept no liability for loss of profit, resultant of indirect damage, any loss of electrical power and / or compensation of energy suppliers within the express meaning of that term. The warranty rights as meant herein are not transferable or assignable to any third party excepting the named warranty holder.

## Warranty Conditions

If a device becomes defective during the agreed Growatt factory warranty period and provided that it will not be impossible or unreasonable, the device will be, as selected by Growatt:

1. Shipped to a Growatt service center for repair.
2. Repaired on-site.
3. Exchanged for a replacement device of equivalent value according to model and age.

The warranty shall not cover transportation costs in connection with the return of defective modules. The cost of the installation or reinstallation of the modules shall also be expressly excluded as are all other related logistical and process costs incurred by all parties in relation to this warranty claim.

## 11.1 Dismantling the inverter

1. Disconnect the storage machine such as mentioned in section 7.
2. Disconnect the upper cable of SPH inverter



Watch out the SPH's shell heat and prevent to scald  
Wait 20 minutes until the SPH cooling and then to disassembly!

3. Unscrew all the connecting cable
4. Unscrew the radiator and wall-mounted anchor screw and then take down the machine from wall.

## 11.2 Package and transport SPH inverter

Usually placed SPH inverter in the packing box with tape sealing, if the SPH inverter cannot reoccupy, you can choose a cheap carton for packaging. Carton requirements must meet the size of the inverter and can support inverter machine overall weight. SPH series frequency converter in the process of moving, please note: handle with care, do not touch the inverter, put as flat as possible.

## 11.3 Storing SPH inverter

Store SPH inverter in a dry place where ambient temperatures are always between -25°C and +60°C

## 11.4 Disposing of the SPH inverter



Do not dispose of SPH inverter together with household waste. Please accordance with the disposal regulations for electronic waste which apply at the installation site at that time. Ensure that the old unit and, where applicable, any accessories are disposed of in a proper manner.

# 12 Product specification

## 12.1 SPH series inverter machine product specification

| Model                                       | SPH 3000TL<br>BL-UP  | SPH 3600TL<br>BL-UP  | SPH 4000TL<br>BL-UP  | SPH 4600TL<br>BL-UP  | SPH 5000TL<br>BL-UP  | SPH 6000TL<br>BL-UP  |
|---|----------------------|----------------------|----------------------|----------------------|----------------------|----------------------|
| Specifications                              |                      |                      |                      |                      |                      |                      |
| Input data(DC)                              |                      |                      |                      |                      |                      |                      |
| Max. recommended PV power(for module STC)   | 6500W                | 7500W                | 8500W                | 9000W                | 9500W                | 10600W               |
| Max. DC voltage                             | 550V                 | 550V                 | 550V                 | 550V                 | 550V                 | 550V                 |
| Start voltage                               | 120V                 | 120V                 | 120V                 | 120V                 | 120V                 | 120V                 |
| Nominal voltage                             | 370V                 | 370V                 | 370V                 | 370V                 | 370V                 | 370V                 |
| MPP work voltage range                      | 120V-550V            | 120V-550V            | 120V-550V            | 120V-550V            | 120V-550V            | 120V-550V            |
| Full load dc voltage range                  | 275V-440V            | 275V-440V            | 275V-440V            | 340V-440V            | 340V-440V            | 340V-440V            |
| Number of independent MPP trackers          | 2                    |                      |                      |                      |                      |                      |
| No. of PV strings per MPP trackers          | 1                    |                      |                      |                      |                      |                      |
| Max. input current per MPP trackers         | 13.5A                |                      |                      |                      |                      |                      |
| Max. short-circuit current per MPP trackers | 16.9A                |                      |                      |                      |                      |                      |
| Backfeed current to the array               | 0A                   |                      |                      |                      |                      |                      |
| AC input / output data                      |                      |                      |                      |                      |                      |                      |
| Rated input / output power                  | 3000/3000 W          | 3680/3680 W          | 4000/4000 W          | 4600/4600 W          | 5000/5000 W          | 6000/6000 W          |
| Rated output apparent power                 | 3000VA               | 3600VA               | 4000VA               | 4600VA               | 5000VA               | 6000VA               |
| Nominal AC voltage/range                    | 230V ; 180Vac-260Vac | 230V ; 180Vac-260Vac | 230V ; 180Vac-260Vac | 230V ; 180Vac-260Vac | 230V ; 180Vac-260Vac | 230V ; 180Vac-260Vac |
| Nominal Frequency                           | 50Hz                 | 50Hz                 | 50Hz                 | 50Hz                 | 50Hz                 | 50Hz                 |
| Rated input / output current                | 13.5/13.5 A          | 16/16 A              | 17.5/17.5 A          | 20/20 A              | 22/22A               | 27/27 A              |
| Max inrush peak current                     | 10A(5ms)             |                      |                      |                      |                      |                      |

| Model   | SPH 3000TL<br>BL-UP     | SPH 3600TL<br>BL-UP | SPH 4000TL<br>BL-UP | SPH 4600TL<br>BL-UP | SPH 5000TL<br>BL-UP | SPH 6000TL<br>BL-UP |
|---|-------------------------|---------------------|---------------------|---------------------|---------------------|---------------------|
| Specifications  |                         |                     |                     |                     |                     |                     |
| Maximum output fault peak current                     | 65A(56uS)               |                     |                     |                     |                     |                     |
| Maximum output over current protection                | 65A                     |                     |                     |                     |                     |                     |
| Phase factor at rate power                            | 1                       |                     |                     |                     |                     |                     |
| Displacement power factor, configurable*              | 0.8leading...0.8lagging |                     |                     |                     |                     |                     |
| THDI  | <3%                     |                     |                     |                     |                     |                     |
| AC connection   | Single phase            |                     |                     |                     |                     |                     |
| Stand alone(AC power)                                 |                         |                     |                     |                     |                     |                     |
| Growatt SPH &SPH TL BL-UP Rated output apparent power | 3000VA                  | 3680VA              | 4000VA              | 4000VA              | 4000VA              | 4000VA              |
| Nominal voltage                                       | 230V                    |                     |                     |                     |                     |                     |
| Rated Frequency AC output                             | 50Hz                    |                     |                     |                     |                     |                     |
| Rated output current                                  | 13A                     | 16A                 | 17.5A               | 17.5A               | 17.5A               | 17.5A               |
| THDv  | 3%                      |                     |                     |                     |                     |                     |
| Switch time(SPH TL BL-UP))                            | ≤10ms                   |                     |                     |                     |                     |                     |
| BAT data (DC)   |                         |                     |                     |                     |                     |                     |
| Battery voltage range                                 | 42~59V                  |                     |                     |                     |                     |                     |
| Minimum full load voltage                             | 46V                     | 48V                 | 48V                 | 48V                 | 48V                 | 48V                 |
| Rated charging and discharging current                | 66A                     | 75A                 | 85A                 | 85A                 | 85A                 | 85A                 |
| Continuous charging / discharging power               | 3000/3000 W             | 3680/3680 W         | 4000/4000 W         | 4000/4000 W         | 4000/4000 W         | 4000/4000 W         |
| Type of Battery                                       | ithium /Lead-acid       |                     |                     |                     |                     |                     |
| Efficiency  |                         |                     |                     |                     |                     |                     |
| Max. efficiency                                       | 97.2%                   | 97.2%               | 97.3%               | 97.4%               | 97.5%               | 97.6%               |

| Model                            | SPH 3000TL<br>BL-UP  | SPH 3600TL<br>BL-UP | SPH 4000TL<br>BL-UP | SPH 4600TL<br>BL-UP | SPH 5000TL<br>BL-UP | SPH 6000TL<br>BL-UP |
|----------------------------------|--|---------------------|---------------------|---------------------|---------------------|---------------------|
| Euro weighted efficiency         | 97%  | 97%                 | 97.1%               | 97.1%               | 97.2%               | 97.2%               |
| MPPT efficiency                  | ≥99.5%   |                     |                     |                     |                     |                     |
| <b>Protection devices</b>        |  |                     |                     |                     |                     |                     |
| Safety level                     | Class II   |                     |                     |                     |                     |                     |
| Overvoltage category             | PV:II AC:III Others:I  |                     |                     |                     |                     |                     |
| Ingress protection               | IP65   |                     |                     |                     |                     |                     |
| Inverter topology                | Non-isolated   |                     |                     |                     |                     |                     |
| Operating temperature range      | -25°C ... +60°C (-13...+140°F) with derating above 45°C /113°F |                     |                     |                     |                     |                     |
| Safety level                     | Class I  |                     |                     |                     |                     |                     |
| Ingress protection               | IP65   |                     |                     |                     |                     |                     |
| DC switch                        | optional <sup>2</sup>  |                     |                     |                     |                     |                     |
| DC reverse-polarity protection   | Integrated   |                     |                     |                     |                     |                     |
| DC Surge protection              | Type II  |                     |                     |                     |                     |                     |
| Insulation resistance monitoring | Integrated   |                     |                     |                     |                     |                     |
| AC surge protection              | Type II  |                     |                     |                     |                     |                     |
| AC short-circuit protection      | Integrated   |                     |                     |                     |                     |                     |
| Ground fault monitoring          | Integrated   |                     |                     |                     |                     |                     |
| Grid monitoring                  | Integrated   |                     |                     |                     |                     |                     |
| Anti-islanding protection        | Integrated(Active Frequency Drift)                             |                     |                     |                     |                     |                     |
| Residual-current monitoring unit | Integrated   |                     |                     |                     |                     |                     |
| <b>General Data</b>              |  |                     |                     |                     |                     |                     |
| Dimensions (W / H / D) in mm     | 565*456*188  |                     |                     |                     |                     |                     |
| Weight                           | 27KG   |                     |                     |                     |                     |                     |
| Noise emission (typical)         | ≤ 25 dB(A)   |                     |                     |                     |                     |                     |
| Altitude                         | 2000m  |                     |                     |                     |                     |                     |

| Model                                  | SPH 3000TL<br>BL-UP   | SPH 3600TL<br>BL-UP | SPH 4000TL<br>BL-UP | SPH 4600TL<br>BL-UP | SPH 5000TL<br>BL-UP | SPH 6000TL<br>BL-UP |
|--|---|---------------------|---------------------|---------------------|---------------------|---------------------|
| Self-Consumption                       | < 10 W  |                     |                     |                     |                     |                     |
| Cooling concept                        | Natural   |                     |                     |                     |                     |                     |
| Relative humidity                      | 100%  |                     |                     |                     |                     |                     |
| <b>Features</b>                        |   |                     |                     |                     |                     |                     |
| DC connection                          | MC4/H4(opt)   |                     |                     |                     |                     |                     |
| AC connection                          | connector   |                     |                     |                     |                     |                     |
| BAT connection                         | OT Terminal   |                     |                     |                     |                     |                     |
| Display                                | LCD   |                     |                     |                     |                     |                     |
| Interfaces: RS485/ USB /CAN/Wi-Fi/GPRS | yes /yes /yes/yes   |                     |                     |                     |                     |                     |
| Warranty: 5 years / 10 years           | yes /opt  |                     |                     |                     |                     |                     |
| Certificates and approvals             | CE, IEC62109, G98/G99, VDE0126-1-1, AS4777, CEI 0-21, VDE-AR-N4105, UTE C 15-712, EN50549, IEC 61727, IEC 62116, IEC 62040 ,,C10/11,NRS 097-2-1 |                     |                     |                     |                     |                     |

**Note:**

1.<sup>1</sup> Continuous charging current: if there is PV and the PV power is large enough, the maximum continuous charging power can reach 4000W; If there is no PV, only AC is connected, the maximum continuous charging power is 3000W.

2.<sup>2</sup> in built DC switch isolator is optional in Australia for SPH .

## 12.2 DC input terminal parameter

MC4 specification:

|                                  | 2.5mm <sup>2</sup> /14AWG   | 4mm <sup>2</sup> /12 AWG | 6mm <sup>2</sup> /10 AWG | 10mm <sup>2</sup> /8AWG |
|----------------------------------|-----------------------------|--------------------------|--------------------------|-------------------------|
| DC connection                    | MC4                         | MC4                      | Mc4                      | MC4                     |
| Rated current (90°C environment) | 32A                         | 40A                      | 44A                      | 65A                     |
| Nominal system voltage           | 600V DC(UL)<br>600V DC(TUV) |                          |                          |                         |
| Contact resistance               | 0.25mΩ (model)              |                          |                          |                         |
| Protection grade                 | IP68                        |                          |                          |                         |

|                           |                              |
|---------------------------|------------------------------|
| Socket contact materials  | Copper, tin                  |
| Insulation materials      | Thermoplastics UL94 V-0      |
| Ambient temperature range | -40℃ to +90℃                 |
| Wire stripping length     | 7.0mm(9/32)                  |
| Cable casing diameter     | 4.5 to 7.8mm(3/16: to 5/16") |

### 12.3 Torque

|                    |                    |
|--------------------|--------------------|
| Upper cover screws | 1.3Nm(10.8 1bf.in) |
| Dc connector       | 1.8Nm(16.0 1bf.in) |
| M6 screwdriver     | 2Nm(18 1bf.in)     |
| Grounding screw    | 2Nm(18 1bf.in)     |

### 12.4 Appendix

The following chart is the inverter machine optional appendix list, if there is a need please contact the Growatt New Energy Technology Co., Ltd or dealer orders (P/N is only for reference and it may be changed).

| Name                                | Description                       | GROWATT P/N  |
|-------------------------------------|-----------------------------------|--------------|
| Shine link-X                        | Used for data record in EU        | MR00.0011200 |
|                                     | Used for data record in Australia | MR00.0011300 |
| Shine Wi-Fi-X                       | COM interface                     | MR00.0011000 |
| SPM-CT-E<br>(Single phase CT meter) | RS485 meter sensor                | MR00.0019000 |
| SPM(Single phase meter)             | RS485 meter sensor                | MR00.0008801 |
| TPM(three phase meter)              | RS485 meter sensor (standard)     | MR00.0008300 |
|                                     | RS485 meter sensor (for Italy)    | MR00.0008400 |

## Product specification 13

Growatt SPH series inverter apply within the scope of the world, so the inverter have to satisfy different countries and regions of different safety standards

| Model  | Certificate   |
|--|---|
| SPH 3000TL BL-UP<br>SPH 6000 TL BL-UP  | CE,IEC62109,G83,VDE0126-1-1,G59,AS4777,AS/NZS3100, CEI0-21,VDE-AR-N4105,EN50438,VFR,MEA,PEA,IEC61727,IEC62116 |
| SPH 3600 TL BL-UP<br>SPH 4000 TL BL-UP<br>SPH 4600 TL BL-UP<br>SPH 5000 TL BL-UP | CE,IEC62109,G83,VDE0126-1-1,G59,AS4777,AS/NZS3100, CEI0-21,VDE-AR-N4105,EN50438,VFR,IEC61727,IEC62116         |

## Contact 14

If you have technical problems about our products, contact the Growatt Service line or dealer. We need the following information in order to provide you with the necessary assistance:

- 1.SPH inverter Serial number
- 2.SPH inverter module information
- 3.SPH inverter communication mode
- 4.SPH inverter fault information code
- 5.SPH inverter Display content
- 6.The manufacturer and model of the battery
- 7.Battery capacity and connection mode

### Shenzhen Growatt New Energy CO.,LTD

4-13/F,Building A,Sino-German(Europe) Industrial Park,  
Hangcheng Ave, Bao'an District, Shenzhen, China

**T** +86 0755 2747 1942

**E** service@ginverter.com

**W** www.ginverter.com